Philips
Remote control

CRP657

Controls your device remotely

Fast and easy control of your device by pressing the buttons.

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS

sense and simplicity

Specifications

Replaceable part

- Fits product types:: 14HT3153/01, 14HT3153/05, 14HT3153/58, 14HT3253/01, 14HT3253/05, 14HT3253/58, 14HT3303/01, 14HT3303/05, 14HT3303/58, 17HT3153/01, 17HT3153/01S, 17HT3153/05, 17HT3153/05S, 17HT3153/58, 17HT3253/01, 17HT3253/01S, 17HT3253/05, 17HT3253/05S, 17HT3253/58, 17HT4203/21M, 17HT4203/25M, 17HT5403/01S, 17HT5403/05S, 20HT3153/01, 20HT3153/05, 20HT3153/58, 20HT3253/01, 20HT3253/05, 20HT3253/58, 20HT3303/01, 20HT3303/05
- Fits product types: 20HT3303/58, 21HT3622/57R, 21HT3627/57Y, 21HT5403/01S, 21HT5403/01Z, 21HT5403/05S, 25HT4677/57Y

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.

Issue date 2011-10-24

Version: 1.0.1

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com